


*RadiantLite*TM **Projector**



Four lights mounted on ceiling plate

The RadiantLite creates three lighting effects in one fixture. First, it creates a concentrated beam of light for display lighting. Next, backlighting for a unique ceiling indirect lighting effect. And lastly, the RadiantLite has a chandelier lighting effect created by the light glimmering through the housing.




Office: 3549 East Reichert Drive, Crete, Illinois 60417
Phone: (708)672-0808, Fax: (708)672-4323
Factory / Repair Dept: 990 Richard Rd, Dyer, IN 46311
Phone: (219)322-8800, Fax: (219)322-8831
E-Mail: RazLight@AOL.COM
Web: RazLight.com

Lighting

RadiantLite™ Specifications

For Interior Use



Changing Lamp: Remove Power and let fixture cool down. Carefully slide lamp shield back and rotate to unhook shield from inner rings. Unplug lamp socket. Loosen lamp rim screws and remove lamp. Reverse process to install lamp.

Changing focus: Loosen screws on lens assembly shaft and move lens assembly up or down shaft.



Office: 3549 East Reichert Drive, Crete, Illinois 60417
Phone: (708)672-0808, Fax: (708)672-4323
Factory / Repair Dept: 990 Richard Rd, Dyer, IN 46311
Phone: (219)322-8800, Fax: (219)322-8831
E-Mail: RazLight@AOL.COM
Web: RazLight.com

Lighting